



342 N. Co. Rd. 400 East
Valparaiso, IN 46383
219-464-8818 • Fax 219-462-7985
www.heatwagon.com

Installation and Maintenance Manual


Please retain this manual for future reference.

VG1000

Construction Heater



City of New York
Dept. of Buildings
29-05-E



For your safety: Do not use this heater in a space where gasoline or other liquids having flammable vapors are stored.

IMPORTANT INFORMATION! READ FIRST

The heater is designed for use as a construction heater under ANSI Z83.7a-2000. Heater is not intended for use in pest remediation. The primary purpose of construction heaters is to provide temporary heating of buildings under construction, alteration, or repair and to provide emergency heat. Properly used, the heater provides safe, economical heating. Products of combustion are vented outside the area being heated.

The heater IS NOT designed as an Unvented Gas Fired Room Heater under ANSI-Z21.11.2 and SHOULD NOT be used in the home.

ANSI A119.2(NFPA 501C)-1987 Recreational Vehicle Standard prohibits the installation or storage of LP-gas containers even temporarily inside any recreational vehicle. The standard also prohibits the use of Unvented Heaters in such vehicles.

NFPA-58 1989 STANDARD FOR THE STORAGE AND HANDLING OF LIQUEFIED PETROLEUM GASES

Use of the heater must be in accordance with this Standard and in compliance with all governing state and local codes. Storage and handling of propane gas and propane cylinders must be in accordance with NFPA 58 and all local governing codes.

We cannot anticipate every use which may be made for our heaters. CHECK WITH YOUR LOCAL FIRE SAFETY AUTHORITY IF YOU HAVE QUESTIONS ABOUT LOCAL REGULATIONS.

Other standards govern the use of fuel gases and heat producing products in specific applications. Your local authority can advise you about these.

FOR YOUR SAFETY

DO NOT USE THIS HEATER IN A SPACE WHERE GASOLINE OR OTHER LIQUIDS HAVING FLAMMABLE VAPORS ARE STORED OR USED.

CONSTRUCTION HEATER GENERAL HAZARD WARNING:

Failure to comply with the precautions and instructions provided with this heater, can result in death, serious bodily injury and property loss or damage from hazards of fire, explosion, burn, asphyxiation, carbon monoxide poisoning, and/or electrical shock.

Only persons who can understand and follow the instructions should use or service this heater.

If you need assistance or heater information such as an instruction manual, labels, etc., contact your local Heat Wagon dealer or the manufacturer.

W A R N I N G

Fire, burn, inhalation, and explosion hazard. Keep solid combustibles, such as building materials, paper or cardboard, a safe distance away from the heater as recommended by the instructions. Never use the heater in spaces which do or may contain volatile or air-borne combustibles, or products such as gasoline, solvents, paint thinner, dust particles or unknown chemicals.

Not for home or recreational vehicle use!

If you have read this entire manual and you still have questions,
please call us at 219-464-8818

Installation and Maintenance Manual

Model VG I 000

Construction Heater

Table of Contents:

	Page
Specifications	4
Safety & Caution	5
Operating Instructions	5
Troubleshooting	8
Maintenance	13
Illustrated Parts Breakdown	16
Wiring Diagrams	23
Exhaust Flue Pipe Guidelines	30
Setting the Pilot	31

WARRANTY

This heater is guaranteed against defective materials and workmanship for one (1) year from Heat Wagon invoice date.

Warranty repairs may be made only by an authorized, trained and certified Heat Wagon dealer. Warranty repairs by other entities will not be considered. Warranty claims must include model number and serial number. Components are guaranteed to the extent of the component manufacturer's warranty.

LIMITATIONS

Warranty claims for service parts (wear parts) such as spark plugs, igniters, and flame rods will not be allowed. Diagnostic parts such as voltage meters and pressure gauges are not warrantable. Evidence of improper fuel usage, fuel pressures outside of manufacturer's specification, poor fuel quality, improper electric power, misapplication and/or evidence of abuse may be cause for rejection of warranty claims.

Labor, travel time, mileage and shipping charges will not be allowed. Minor adjustments to heaters are the responsibility of the dealer. Defective parts must be tagged and held for possible return to the factory for 60 days from date of repair. The factory will provide a return goods authorization, (RGA) for defective parts to be returned. No warranty will be allowed for parts not purchased from Heat Wagon.



342 N. Co. Rd. 400 East • Valparaiso, IN 46383
219-464-8818 • 888-432-8924 • Fax 800-255-7985
www.heatwagon.com

SAFETY & CAUTION

- Instructions given in this manual and the applicable regulations of the local authorities must be followed.
- The unit may be operated only by those persons who have been instructed in its proper use.
- The unit is to be installed and operated in such a way as to ensure the safety of employees and surroundings.
- Never cover the unit's air openings.
- Always ensure adequate fresh air supply to the unit.
- Never stand in front of the discharge end of the heater.
- Keep a minimum clearance of 10 feet from the fuel source. Storing and use of liquid fuel must comply with the regulations and instructions given by the local authorities.
- Unit's emitted noise level at the range of 3 feet: 74 dBA.
- Do not introduce foreign objects into the unit.
- Do not expose the unit to direct water jets.
- All electric cables outside the unit are to be protected against damage.
- Always disconnect the unit from power supply and turn off the gas supply when maintenance or service is being performed.
- IF NOT OPERATED WITHIN GUIDELINES OF THESE OPERATING INSTRUCTIONS, MANUFACTURER WILL NOT BE HELD RESPONSIBLE AND WARRANTY WILL BECOME VOID.

OPERATING INSTRUCTIONS

INSTALLATION

- When transporting, use both lifting eyes located on sides of heater.
- Place the unit on a level and non-combustible surface.
- Minimum clearances from combustibles:
 - outlet, minimum 10 feet
 - sides, minimum 3 feet
 - top, minimum 3 feet
 - flue pipe exhaust minimum 2 feet
- Manufacturer recommends a free zone of 5 feet around the unit and a minimum distance of 10 feet at the unit's flue gas openings are to be maintained.
- If the unit is placed indoors, secure an adequate fresh air opening for the burner combustion air.
- The unit may not be installed and operated in premises where explosive or combustible fumes or dust are present. Always check the regulations of local authorities.
- Be certain that neither the air inlet nor the air outlet is obstructed.

FUEL SUPPLY

- This heater is shipped as either natural gas or vapor propane. Check for proper pilot orifice in burner (Midco burner only).
 - Natural Gas .052
 - Vapor Propane .046
- Be certain to use adequate hose or pipe size to ensure proper volume and pressure.
See Chart Below.

VAPOR PROPANE QUICK REFERENCE HOSE CHART

Hose Length in Feet	BTU 1 Million	
	1/2PSI	10PSI
10	1-1/4	3/4
25	1-1/4	3/4
35	1-1/2	3/4
50	1-1/2	3/4
75	2	3/4
100	2	3/4
125	2	3/4
150	2	3/4
175	2	3/4
200	2	3/4
225	2	3/4

NATURAL GAS QUICK REFERENCE HOSE CHART

Hose Length in Feet	BTU 1 Million			
	<1PSI	1PSI	2PSI	5PSI
10	1-1/2	1-1/4	3/4	3/4
25	2	1-1/4	3/4	3/4
35	2	1-1/4	3/4	3/4
50	2	1-1/4	1	3/4
75	2	1-1/4	1-1/4	3/4
100	2	1-1/4	1-1/4	3/4
125	2-1/2	1-1/2	1-1/4	1
150	2-1/2	1-1/2	1-1/4	1
175	2-1/2	1-1/2	1-1/4	1
200	2-1/2	1-1/2	1-1/4	1-1/4
225	2-1/2	1-1/2	1-1/4	1-1/4

For supply pressures greater than 1/2psi

- A regulator must be installed on the heater to ensure that the pressure to the heater does not exceed 1/2 psi inlet pressure. Excessive pressures over 1/2 psi (14" W.C.) will damage controls and void warranty.



FUEL SUPPLY (CONTINUED)

- Ensure that for the surrounding temperature, size and capacity of the propane supply cylinder is adequate to provide the rated Btu/hr input to the heater.
- Visually inspect the hose assembly and ensure that it is protected from traffic, building materials, and contact with hot surfaces. If it is evident that there is excessive abrasion or wear, or the hose is cut, replace it immediately.
- Purge air from line and wait 10 minutes for gas to dissipate.
- After installation, check the hose assembly for gas leaks by applying a water and soap solution to each connection.
- Fuel hose must be UL approved.
- The installation of this heater to a natural gas supply must confirm with all applicable local codes or, in the absence of local codes, with the National Fuel Gas Code ANSI Z223.1/NFPA 54. For vapor propane, refer to standard for Storage and Handling of Liquefied Petroleum Gases ANSI/NFPA 58.

ELECTRICAL

- Electric cable extensions must be connected by qualified authorized electricians based on the unit capacity and cable length.
- Connect unit to a power supply with a suitable appliance receptacle (30 Amp). Green indicator lamp will light up.
- Confirm voltage at heater connection (208V min.) to ensure proper operation.

EXHAUST FLUE PIPE

- The unit is to be connected to a flue pipe with adequate draft, to ensure the proper start and operation of the unit. Refer to page 27.
- The flue pipe is to be made of non-combustible material and clearances from combustible materials must be a minimum 8 inches (temperature of flue gases is approximately 410° F).
- The flue pipe and its installation must comply with the regulations and instructions given by the local authorities.

START UP

- Only people trained in the operation and supervision of this heater should operate and maintain the unit.
- Check the unit to make certain that there are no visible defects on the control and safety devices and that the unit has been installed correctly.
 1. Open door at back of unit (control box compartment).
 2. Check that the control switch in the control box is in position "0" (STOP).
 3. Pre-select desired room temperature on the room thermostat. The temperature must be set higher than the ambient temperature.
 4. Open all possible shut-off devices of the fuel supply lines and push the reset on the low pressure gas switch (Wayne Burner Only).

START UP (CONTINUED)

5. Turn the control switch in control box to position "1" (HEATING).
 6. When the ambient temperature level is lower than thermostat setting, the burner switches on automatically. The fan does not switch on until the set temperature (104°F) of the heat-exchanger has been reached (will take approximately 1-5 minutes).
 7. The green indicator lamps for "heating on" and "fan on" will light up now.
 8. Close the door in order to protect the unit against unauthorized adjustments.
- After startup, the heater is operated automatically by the room thermostat and governed by all control devices, including the safety limit controls.
 - The room thermostat (TSTAT) and burner sensor control the running sequences of the burner and the fan sensor controls the fan function.
 - Overheat limit reset (STB) controls and shuts off the heater (burner) in the case of overheating.
 - The unit can also be used for ventilation purposes only, if needed.
 1. Turn the control switch in control box to position "2" (VENTILATION).
 2. The unit is now in the continuous ventilating mode.
 3. Heating is not possible in this mode.

DUCTING (Warm Air)

- Minimum clearance from combustible materials is 4 inches.
- Use steel ducting or fabric ducting capable of withstanding maximum temperature of 300°F.
- Maximum length of duct: 200' (straight).
- Duct diameter: 20".
- Make certain that the duct is safely and properly fastened to the warm air outlet.
- Avoid sharp bends and corners to ensure maximum air flow and avoid back pressure that can cause heat accumulation in heater.
- FAILURE TO COMPLY WITH THESE RECOMMENDATIONS COULD RESULT IN SHUTDOWN OF THE HEATER.

SHUT DOWN

- Turn control switch to position "0" (STOP).
- Close fuel supply.

Important!

The air supply fan continues running for several minutes to cool down the combustion chamber/heat exchanger. The fan can restart several times before finally switching off!

WARNING!

ELECTRICAL POWER TO THE UNIT MAY BE DISCONNECTED IN EMERGENCY SITUATIONS ONLY. OTHERWISE, DO NOT STOP THE UNIT BY DISCONNECTING POWER. UNIT NEEDS TO COOL DOWN USING ITS OWN FAN. FAILURE TO COMPLY WITH PROPER SHUT-DOWN PROCEDURES CAN CAUSE DAMAGE TO THE COMBUSTION CHAMBER, HEAT EXCHANGER, SAFETY FEATURES AND VOID WARRANTY.

VG1000 TROUBLESHOOTING- Use after proper setup requirements have been achieved.

Symptom

Possible Causes

Possible Solutions

1. Turn the heater to position #1 and nothing happens.

- Power supply cord
- Burner reset button on the burner flame safeguard control box is engaged
- Overheat limit switch is tripped

- Test for 240 volts (min 208) between L1 and L2 on the main terminal block.
- Reset the blue button on the flame safeguard control.

• Reset the switch, which is located in the burner compartment on the gray box on the left hand side of the burner.

- Burner motor relay is located in the main control box (K2). Check between ground and L1, then ground and T1 for 120 volts. If less than 105 volts replace relay.

• On the heater control unit (HCU) disconnect the wires from terminals X10 and X11. Using an ohm meter, check the resistance between the two wires for a reading. Compare to Sensor Resistance Chart page 26.

Replace sensor if reading is out of range.

- On the main terminal block, check for 120 volts between terminals 8 and N when the 3-position switch is in the HEAT position. If less than 105 volts, replace HCU.

2. Burner motor comes on, but the heater won't ignite.

- Pilot (Midco Burner Only)
- Fuel pressure or volume

• See instructions on page 31

- Use a low pressure gauge (0-15 inches of water column) with 1/8" NPT inlet. Install gauge in the pressure tap port located on the output side of the gas valve. Run the heater. Adjust the pressure by turning the pressure adjusting screw (located on the input side top of the gas valve) counter clockwise until the gauge reads the proper manifold pressure. Refer to pipe sizing charts in the Heat Wagon Engineering Guide. Heater requires 9-14" W.C. inlet pressure. Ensure proper purge procedure (see Fuel Supply Installation).

• Air inlet damper adjustment

- Rough setting at 1/2 open. Minor adjustments from the rough settings can be made to achieve a smooth sounding burner with no soot from the flue pipe. Insert volt meter probes into provided + and – terminals on the Honeywell Flame Safeguard Control. Set the volt meter on DC volts and run the heater. Adjust the air damper until the volt meter reads the highest voltage between 2 and 5 volts.

• Ignition electrode

- Clean with fine sandpaper. Make sure it is free from buildup or cracks.

Continued on next page



VG1000 TROUBLESHOOTING

Symptom

2. Burner motor comes on, but the heater won't ignite.

Possible Causes

- Electronic igniter
- Burner airflow switch
- Gas valve
- Pressure switches (Wayne burner only)

Possible Solutions

- Turn off the gas valve, turn on the burner. Use insulated pliers to hold the ignition wire and short it to ground. Pull the wire away from ground slowly. A rainbow colored arc should travel between the wire and the ground at a distance of 3/8 of an inch for a duration of 4-5 seconds.
 - The burner airflow switch (located above blue Honeywell safeguard control) will not allow power to the flame safeguard control when it is open. Check the tubes supplying air to the switch for any restrictions. ONLY AS A TEST, wire around the air switch. If this test solves the problem, adjust or replace the switch (Midco Burner Only).
 - If there is power at the flame safeguard control and no power out to the solenoid valves, replace the flame safeguard control. Check for continuity between the terminals on the solenoid valve coil. If no continuity, replace gas valve.
 - Make sure both reset buttons are depressed. (Items 14 and 15 on page 22) *These switches typically activate when unit runs out of fuel.*
-
- Clean with fine sandpaper and check metal for fatigue and ceramic of any hairline cracks.
 - Set multimeter to D.C. volts, insert test leads (red positive, black negative) into corresponding holes located on the front face of the Honeywell control.
 - Use a low pressure gauge (0-15 inches of water column) with 1/8" NPT inlet. Install gauge in the pressure tap port located on the output side of the gas valve. Run the heater. Adjust the pressure by turning the pressure adjusting screw (located on the input side top of the gas valve) counter clockwise until the gauge reads the proper manifold pressure. Refer to pipe sizing charts in the Heat Wagon Engineering Guide. Heater requires 9-14" W.C. inlet pressure. Ensure proper purge procedure (see Fuel Supply Installation).
 - Rough setting at 1/2 open. Minor adjustments from the rough settings can be made to achieve a smooth sounding burner with no soot from the flue pipe. Insert volt meter probes into provided + and - terminals on the Honeywell Flame Safeguard Control. Set the volt meter on DC volts and run the heater. Adjust the air damper until the volt meter reads the highest voltage between 2 and 5 volts.

3. The burner lights for only 5 seconds and then shuts down

- Flame sensor
- Flame safeguard
- Fuel pressure or volume
- Air inlet damper adjustment

Symptom

Possible Causes

Possible Solutions

4. The heater runs for a little while, but shuts down. It won't come on again until the limit switch is reset.

- Incorrect burner manifold pressure
- Restricted airflow
- Overheat limit switch

- (Midco Burner) Use a low pressure gauge (0-15 inches of water column) with a 1/4" NPT inlet. Install gauge in the pressure tap port located on the output side of the last gas solenoid valve in line. Run unit and adjust the manifold pressure by turning the pressure adjusting screw (located in the center of the Maxitrol RV81 regulator) in or out until the gauge reads 2.6 inches of W.C. for propane or 4.1 inches of W.C. for natural gas. (Wayne Burner) 3 inches of W.C. for propane or 3.5 inches of W.C. for natural gas.
- Check for dirt or ice buildup on the air inlet or blower wheel. If using duct on the air outlet, ensure the back pressure does not exceed a static pressure of .2" W.C. Check with magnehelic gauge if necessary.
- Adhere to the proper shut down procedures.

Power must remain at the unit until it cools down fully. Blower will shut down on its own when cool. Test overheat limit switch for continuity between the two male terminals at room temperature. Replace if overheat limit switch fails test. The limit switch is located in the upper left hand corner of burner compartment.

5. The heater has a loud rumbling sound.

- Air damper setting
- Dirt on burner blower wheel
- Flue pipe setup or flue pipe restrictions
- Gas manifold pressure

- Rough setting at 1/2 open. Minor adjustments from the rough settings can be made to achieve a smooth sounding burner with no soot from the flue pipe. Insert volt meter probes into provided + and – terminals on the Honeywell Flame Safeguard Control. Set the volt meter on DC volts and run the heater. Adjust the air damper until the volt meter reads the highest voltage between 2 and 5 volts.
- Clean the burner blower wheel with a small brush
- Refer to the flue pipe chart in this manual. Check flue for restriction
- Use a low pressure gauge (0-15 inches of water column) with 1/8" NPT inlet. Install gauge in the pressure tap port located on the output side of the gas valve. Run the heater. Adjust the pressure by turning the pressure adjusting screw (located on the input side top of the gas valve) counter clockwise until the gauge reads the proper manifold pressure. Refer to pipe sizing charts in the Heat Wagon Engineering Guide. Heater requires 9-14" W.C. inlet pressure.
- Refer to the cleaning instructions in this manual.

- Heat exchanger



VG1000 TROUBLESHOOTING

Symptom

6. The heater blows black smoke out of the vent stack.

Possible Causes

- Air damper setting
- Dirt on burner blower wheel
- Flue pipe setup or flue pipe restrictions
- Gas manifold pressure
- Heat exchanger

Possible Solutions

- Rough setting at 1/2 open. Minor adjustments from the rough settings can be made to achieve a smooth sounding burner with no soot from the flue pipe. Insert volt meter probes into provided + and – terminals on the Honeywell Flame Safeguard Control. Set the volt meter on DC volts and run the heater. Adjust the air damper until the volt meter reads the highest voltage between 2 and 5 volts.
- Clean the burner blower wheel with a small brush
- Refer to the flue pipe chart in this manual. Check flue for restriction
- Use a low pressure gauge (0-15 inches of water column) with 1/8" NPT inlet. Install gauge in the pressure tap port located on the output side of the gas valve. Run the heater. Adjust the pressure by turning the pressure adjusting screw (located on the input side top of the gas valve) counter clockwise until the gauge reads the proper manifold pressure. Refer to pipe sizing charts in the Heat Wagon Engineering Guide. Heater requires 9-14" W.C. inlet pressure.
- Refer to the cleaning instructions in this manual.

7. The burner seems to cycle on and off more frequently than what it should.

- Gas manifold pressure
- Dirt on main air blower or setup of outlet air duct
- Burner sensor
- Heater Control Unit (HCU)

- Use a low pressure gauge (0-15 inches of water column) with 1/8" NPT inlet. Install gauge in the pressure tap port located on the output side of the gas valve. Run the heater. Adjust the pressure by turning the pressure adjusting screw (located on the input side top of the gas valve) counter clockwise until the gauge reads the proper manifold pressure. Refer to pipe sizing charts in the Heat Wagon Engineering Guide. Heater requires 9-14" W.C. inlet pressure.
- Check for dirt or ice buildup on the air inlet or blower wheel. If using duct on the air outlet, ensure the back pressure does not exceed a static pressure of .5" W.C.
- On the heater control unit (HCU) disconnect the wires from terminals X10 and X11. Using an ohm meter, check the resistance between the two wires for a reading. Compare to Sensor Resistance Chart page 25. Replace sensor if reading out of range.
- If all of the above check good, replace the HCU.

VG1000 TROUBLESHOOTING

Symptom

Possible Causes

- | | |
|---|---|
| <p>8. The burner starts, but the main fan never comes on.</p> | <ul style="list-style-type: none"> • Fan sensor • Heater Control Unit (HCU) • Blower motor relay • Current overload on blower motor • Blower motor |
|---|---|
-
- | | |
|---|--|
| <p>9. The burner continues to run, but the fan cycles on and off.</p> | <ul style="list-style-type: none"> • Gas manifold pressure • Fuel supply pressure and volume • Fan sensor |
|---|--|

Possible Solutions

- On the heater control unit (HCU) disconnect the wires from terminals X12 and X13. Using an ohm meter, check the resistance between the two wires for a reading. Compare to Sensor Resistance Chart page 25.
 - Turn the 3-position main switch to the fan position. If the blower runs, check the fan sensor. If it is good, replace the HCU.
 - Turn the 3-position main switch to the fan position. If the relay pulls in, check for voltage between the L1 and L2 terminals. Then check the voltage between terminals T1 and T2. The voltage should be the same. If it is less than 105 volts, replace the relay.
 - Push the reset button on the overload between terminals A1 and A2 on the motor relay. If there is no voltage, replace the overload.
 - Turn the 3-position main switch to the fan position. Check for voltage between terminals T1 and T2 on the motor relay. If the voltage checks at 120 volts, replace the motor.
-
- Use a low pressure gauge (0-15 inches of water column) with 1/8" NPT inlet. Install gauge in the pressure tap port located on the output side of the gas valve. Run the heater. Adjust the pressure by turning the pressure adjusting screw (located on the input side top of the gas valve) counter clockwise until the gauge reads the proper manifold pressure. Refer to pipe sizing charts in the Heat Wagon Engineering Guide. Heater requires 9-14" W.C. inlet pressure.
 - Use a low pressure gauge (0-15 inches of water column) with 1/8" NPT inlet. Install gauge in the pressure tap port located on the output side of the gas valve. Run the heater. Adjust the pressure by turning the pressure adjusting screw (located on the input side top of the gas valve) counter clockwise until the gauge reads the proper manifold pressure. Refer to pipe sizing charts in the Heat Wagon Engineering Guide. Heater requires 9-14" W.C. inlet pressure.
 - On the heater control unit (HCU) disconnect the wires from terminals X12 and X13. Using an ohm meter, check the resistance between the two wires for a reading. Compare to Sensor Resistance Chart page 26. If the test falls out of this range, replace fan sensor.
 - Turn the 3-position main switch to the fan position. If the blower runs, check the fan sensor. If it is good, replace the HCU.



MAINTENANCE

Prior to starting any maintenance work be sure to disconnect unit from power supply until unit cools down fully and fan shuts off! (Shut Down Procedures page 7)

To ensure the proper function of the unit, it must be serviced on regular basis. Maintenance can be performed, excluding the control devices and safety limit controls, by an authorized trained & certified Heat Wagon dealer. The control devices and safety limit controls do not need routine maintenance. If these items fail they must be replaced.

- Do not use any aggressive cleaning agents, which are harmful or environmentally unfriendly, when cleaning the unit.
- Do not use water jet when cleaning the unit.
- Pressurized air may be used for maintenance. Be careful not to damage the fan blower wheel with too much pressure.
- Check whether the unit is free from mechanical damage, replace faulty parts as necessary.
- Check fan blower wheel of the fan at regular intervals and clean it when needed.
- Check functionality of control and safety devices regularly.
- Have the flue gas values of the burner checked regularly by authorized agents.
- Be sure to store the unit in a dust free and dry place when it is not used for a long period of time. Cover the exhaust flue to prevent entry of foreign objects.

SERVICE

- The complete unit, including heat exchanger, combustion chamber and burner should be cleaned from dust and dirt after every heating period, at a minimum of once per year.

Removal of combustion chamber:

For proper cleaning of the unit, manufacturer recommends removal of the complete combustion chamber with heat exchanger.


Disassembling of burner:

1. Disassemble four tightening bolts on the combustion chamber flange and remove burner's mounting flange. Take care not to damage the flange seal.
2. Pull out the burner. Take care not to damage the burner head and power cable.

Next step:

1. Pull off collar (1) from flue gas adapter after having removed the fixing screws.
 2. Disassemble flue gas adapter (2) from combustion chamber and pull it off.
 3. Disassemble center side panel (3) and insulation (4).
- Manufacturer recommends removing the left center side panel (seen from the control box end).
4. Disassemble tightening bolts at supports of combustion chamber (5) and pull out combustion chamber sideways.


Important! Take care not to bend or damage supports of combustion chamber!



Heat exchanger

When cleaning the heat exchanger:

1. Disassemble revision cover of heat exchanger (1).
2. Be careful not to tear or damage gasket.
3. Pull all flue gas suppressors (5) (all 15 pcs) out from flue gas passages. Do not bend them.
4. Clean all flue gas passages (6) with a brush or vacuum cleaner.
5. Clean flue gas suppressors or replace them, as necessary.
6. Check gasket of revision cover and replace, as necessary.



Combustion chamber

When cleaning the combustion chamber:

1. Clean combustion chamber (7) through its opening (8) with a vacuum cleaner.

Burner

When servicing the burner:

1. Read the operating and maintenance instructions of the gas burner.
2. Make sure that the burner is exclusively maintained by authorized agents.

Re-assembly of the unit.

Heat exchanger:

1. Replace all removed parts in reverse order.
2. Make sure that the gaskets and the revision cover (1) are correctly seated.


Combustion chamber and burner:

1. Carefully assemble combustion chamber into unit and adjust it. Hand tighten bolts (final tightening after installing the burner's mounting flange).
2. Install burner's mounting flange.
3. Check flange gasket and replace, if necessary.
4. Tighten the screws of combustion chamber supports.
5. Remount all trim panels.
6. Remount flue gas adapter, check gaskets and replace, if necessary.
7. Install burner to the mounting flange. Take care not to damage the burner head and power cable.
8. Re-install all connections and joints and check them thoroughly.
9. Put unit into service and check proper function of all operating modes.
10. Adjust the burner, if necessary.

Important!

An operation or use other than that indicated in these instructions is prohibited!

VG1000
PARTS
BREAKDOWN



ITEM	PART#	DESCRIPTION
1	HWP 214401	Flue Gas Adapter
2	HWP 214402	Cover Plate, Rear
3	HWP 214403	Connecting Profile
4	HWP 214404	Cover Plate, Front
5	HWP 214405	Crane Eye (4)
6	HWP 214406	Air Outlet Adapter
7	HWP 20529	Flange Seal
8	HWP 20471	Oil Burner Flange
9	HWP 110121	Fuel Filter
10	HWP 110008	Oil Burner
	HWP 110008B	Gas Burner
11	HWP 214411	Burner Compartment Door
12	HWP 214412	Base
13	HWP 214413	Oil Collector
14	HWP 214414	Insulation, Center (left/right)
15	HWP 214415	Insulation, Burner End (left/right)
16	HWP 214416	Side Panel, Burner End (2, with louvres)
17	HWP 214417	Side Panel, Center (left/right)
18	HWP 214418	Air Inlet Adapter (1, left/right/right options)
19	HWP 214419	Louvre Panel, Fan End (2, left/right/right options)
20	HWP 214420	Upper Side Panel, Fan End (2)
21	HWP 214421	Radial Fan
22	HWP 214422	Door Belt
23	HWP 214423	Control Compartment Door
24	HWP 214424	Main Control Box
25	HWP SM6162	Fan Motor

ITEM	PART#	DESCRIPTION
27	HWP 214427	Guide Rail (2 Required)
28	HWP 214428	Combustion Chamber & Heat Exchanger
29	HWP 214429	Air Outlet Cone

Not Shown

HWP 80200	Power Cord & Plug (2 PCS.)
HWP 214430	Top Radiation Shield
HWP 214432	Revision Cover
HWP 86250F	Gasket for Revision Cover
HWP 214434	Flue Gas Suppressors
HWP 214435	Drive Pulley, Fan
HWP 3070	Heat Wagon Logo Decal
HWP 214490	Smoke Flue w/Raincap
HWP 842920	Cover for Honeywell Flame Safeguard Control
HWP 86250F	Fiberglass Gasket Material
HWP 63817001	Burner Gasket
HWP 20582	Fan & Burner Sensor
HWP 65900	Compression Fitting for Temp. Sensors
HWP 63817001	Wayne Burner Gasket

ACC CLUTCHKIT




HWP A68	V-Belt (2 Required)
HWP 1800P017	Motor Clutch
HWP 2AK104H/H-1	10-1/4" Fan Sheave
HWP H-25MM	Sheave Bushing

Obsolete

HWP 214500	Centrifugal Clutch/Motor Sheave
HWP 214501	11-3/8" Fan Sheave
HWP 214502	Sheave Bushing Fan

Also see Control Box Parts page 28.




**MIDCO BURNER
PARTS BREAKDOWN**

ITEM	PART#	DESCRIPTION
1	HWP 6712-05	Flame retention plate with mounting
2	HWP 6736-00	Adj. alloy sleeve
3	HWP 6755-10	Drawer assembly with pilot and vent tube
5	HWP 3197-50	Motor mounting plate
6	HWP 3246-08	Air shutter
7	HWP 6734-00	Air shutter shaft
8	HWP 3152-01	Quadrant - for air shutter adjustment
9	HWP 6724-10	Blower inlet screen
10	HWP 3627-50	G58 & G69-7" diameter x 3-1/2" wide
11	HWP 8437-15	G58-1/2 HP 115/230/1/60
12	HWP 6717-90	Flamerod wire replacement kit
14	HWP 8409-10	Silicone boot
15	HWP 8502-05	Spark cable
16	HWP 6725-90	Pilot with flame sensor and spark rod
17	HWP 6717-00	Flame sensor and insulator assembly
18	HWP 6720-90	Mounting clamp for flamerod assembly
19	HWP 6725-50	Spark rod and insulator assembly
20	HWP 6764-00	Spark rod retainer assembly w/O-ring seal
21	HWP 8432-07	Spark rod retainer O-ring
22	HWP 8402-00	Gas safety shut-off valve - 1/8" NPT
23	HWP 8447-22	Ignition trans 120/1/60
24	HWP 6729-91	Pilot air tube blower housing
25C	HWP 6766-02	Nat. G58 gas #55 Dr. (.052), air #26 Dr. (.147)
25G	HWP 6766-07	Prop G58 gas #56 Dr. (.046), air #26 Dr. (.147)
26	HWP 8429-19	RM7895A Controller
32	HWP 8425-19	Blower air switch
33	HWP 8418-21	1" diaphragm valve
34	HWP 8402-06	1-1/4" safety valve
35A	HWP 8416-02	RV61 1-1/4" Maxitrol gas pressure regulator
36	HWP 2933-50	On/off butterfly valve
44	HWP 8400-10	Pilot pressure regulator
45	HWP 8404-24	Shut-off valve with port
46	HWP 6735-00	Main gas manifold


Not Shown

HWP HV1169	Gauge 15" W.C. Low Pressure (2)
HWP 74689	ST7800 for RM7895 30 seconds
HWP 842927	R7847A for RM7895 rectification amplifier
HWP 63771-001	O7800 sub-base
HWP 842920	Cover for 842919 Primary Control
HWP 5616-90	Strain relief bushing for spark cable

WAYNE BURNER
PARTS BREAKDOWN



WAYNE BURNER
PARTS BREAKDOWN



ITEM	PART#	DESCRIPTION	ITEM	PART#	DESCRIPTION
1	HWP 63587-001	Housing LC1000 Base Burner	23	HWP 842927	Amplifier, Flame
2	HWP 20370-004	Box, Junction Deep Mach	24	HWP 74689	Timer, Purge
3	HWP 62407001	Igniter, Transformer 120V	25	HWP 63497003	Wire, Control Sense
4	HWP 13801	Fitting, Conduit 3/8	26	HWP 31954-001	Strain Relief, Low Profile
5	HWP 13034	Bushing, Snap	27	HWP 13801-002	Fitting, Conduit
6	HWP 63747-001	Fitting, Adapter	28	HWP 15323	Connector, Conduit
7	HWP 550052	Fitting, Hose	29	HWP 100196-019	Conduit, Flex 3/8" x 12
8	HWP 63599-001	Motor, 1/2HP 120V	30	HWP 14429	Connector, Conduit Duplex
9	HWP 63593-001	Plate, Sense Bushing	31	HWP 100196-016	Conduit, Flex 3/8" x 19.50
10	HWP 62389-002	Bushing, Terminal	32	HWP 15731	Screw, 6-32 Hexslt
11	HWP 13026	Bushing, Strain Relief	33	HWP 18001	Screw, 1/4-20 x .75
12	HWP 63801001	Tube, Clear Vinyl 1/4 x 9.5			
13	HWP 62909004	Wire, Ignition		Not Shown	
14	HWP 100408-002	Nut, Lock 1/4 - 20 HXSR	HWP HV1169	Gauge 15" W.C. Low Pressure (2)	
15	HWP 63743-001	Wire, Sense Electrode (not shown)	HWP 63804	Electrode	
16	HWP 63263-005	Switch, Air Sensing	HWP 63805	Flame Sensor	
17	HWP 63800001	Blower Wheel	HWP 842920	Cover for HWP 842919 Primary Control	
20	HWP 63769-001	Bracket, Control Mounting "L"			
21	HWP 842919	Primary Control			
22	HWP 63771-001	Wiring Subbase			

WAYNE BURNER SERVICING

Caution: Make sure that the main manual gas valves and main electrical power disconnect are turned off before opening burner or removing any parts for service. All cover plates, enclosures, and guards must be in place at all times, except during maintenance and servicing.

A. BURNER HEAD AND ELECTRODE/SENSOR ASSEMBLY


The burner head, electrodes, and manifold pipe are part of the gas pipetrain assembly. (See Figure 21) To remove the burner head assembly, follow the procedure outlined below:

- Disconnect the union fitting closest to the burner in the gas pipetrain.
- Remove the four allen head screws that hold the manifold pipe to the burner housing.
- Remove the retaining nut that holds the hinged flange together and swing the fan housing slightly to the side. It may be necessary to disconnect the electrical supply to the control panel (if mounted on the burner). Before doing so, make sure the electrical supply is off.
- Disconnect the ignition wire from the electrode and the sensing wire from the flame rod. Swing the fan housing to the side.
- Remove the allen screw that holds the head adjustment knob in place. Remove the knob.
- Remove the scrow on the left side of the burner head assembly and pull the head assembly out of the burner.

When servicing, clean burner head ports, electrodes and sensor probe. Inspect the sensor probe and electrode wires and porcelain insulators carefully for hairline cracks, which might provide an electrical leak path that could short out the ignition spark, or flame signal.

Examine the electrode and sensor probe for any serious corrosion or deterioration of metal at the tips. Check for proper dimensional settings of the sensor probe and electrode. Adjust and/or replace these assemblies as necessary. Make sure that the ignition and sensor probe wires go to the correct electrodes and the ignition wire boot is in place over the electrode porcelain.

Make sure that the burner tube end is properly positioned in the combustion chamber entry. It must be set 1/2" (12.7mm) short of the inside face of the combustion chamber.



ELECTRODE SETTING

WAYNE BURNER SERVICING






Figure 21

WAYNE BURNER COMBUSTION SYSTEM





ITEM	PART#	DESCRIPTION	ITEM	PART#	DESCRIPTION
1	HWP 63751-001	Reducer, Bell 1" x 1-1/4"	21	HWP 101275-001	Plug, Hex Head 1/8 Brass
2	HWP 63262004	Regulator, Gas Pressure	22	HWP 63526-001	Nipple, Hex 1/4" x 1/8"
3	HWP 63752-008	Nipple, 1-1/4" x 11"	23	HWP 100462-001	Nipple, Pipe 1/8" x 1-1/2"
4	HWP 63752-004	Nipple, 1-1/4" x 7"	24	HWP 13801	Fitting, Conduit 3/8
5	HWP 63756-001	Valve, Manual Ball 1-1/4"	25	HWP 14429	Connector, Duplex Conduit
6	HWP 63947-001	Elbow, 1-1/4" 90°	26	HWP 100196-024	Conduit, Flex 3/8" x 13"
7	HWP 63755-001	Union, 1-1/4"	27	HWP 100196-003	Conduit, Flex 3/8" x 5"
8	HWP 63948-001	Elbow, 1-1/4" 90° Female	28	HWP 100196-006	Conduit, Flex 3/8" x 10"
9	HWP 63759-001	Valve, Gas Safety Sutoff 1-1/4"	29	HWP 100196-019	Conduit, Flex 3/8" x 12"
10	HWP 63752-003	Nipple, 1-1/4" x 6-1/2"	30	HWP 63523-001	Plug, P88H 1" Plastic
11	HWP 63752-006	Nipple, 1-1/4" x 13-1/2"	31	HWP 63523-002	Plug, P108 1-1/4" Plastic
12	HWP 63752-001	Nipple, 1-1/4" x 2"	32	HWP 12910	Locknut, Conduit
13	HWP 63752-007	Nipple, 1-1/4" x 4"	33	HWP 63528-001	Decal, Gas Inlet
14	HWP 63513001A	Switch, Gas Pressure Low	34	HWP 63528-002	Decal, Gas Outlet
15	HWP 63513002A	Switch, Gas Pressure High	35	HWP 13660	Bushing, ASB-1
16	HWP 13385	Elbow, Street 1/8"NPT	36	HWP 63958-001	Elbow, 1-1/4" 90°
17	HWP 100462-004	Nipple, Pipe 1/8" x 2-1/2"	38	HWP 62411-073	Wire, Black 16GA
18	HWP 63719-001	Elbow, Pipe 90° ELL 1/8"NPT	39	HWP 63012-001	Terminal Female .250 Insulated
19	HWP 100462-005	Nipple, Pipe 1/8" x 5"	40	HWP 62411-083	Wire, White 16GA
20	HWP 63521-002	Tee, 1/8" Blk Pipe	41	HWP 63012-002	Terminal, Male .250 Insulated

MIDCO BURNER VG1000




ABBREVIATION	NO.	COLOR	NO.	COLOR	NO.	COLOR
BL	BL	BLACK	L1	BK	F	BLACK
BK	BK	BROWN	L2	W	G	GREEN
BR	BR	BROWN	3	O		
O	R	RED	4	R		
R	W	WHITE	6	BK		
W	W	WHITE	7	BRN		
Y	Y	YELLOW	8	BRW		
GRN	G	GREEN	9	BLW		
STR	STR	BLACK STRIPE	10	BL		
W STR	W STR	WHITE STRIPE				
NJ	NJ	NOT USED				
PGT	PGT	POTENTIAL				


- LEGEND:**
- SOLID WIRING AND COMPONENTS BY MIDCO
 - DASHED WIRING AND COMPONENTS BY INSTALLER
 - OPTIONAL WIRING AND COMPONENTS BY MIDCO
 - ENCIRCLED: FLAME SAFEGUARD
 - SOLID ROUND: BURNER STRIP
 - OPEN ROUND: COMPONENT
 - LIGHT (LOCATED IN GAS SWITCH ENCLOSURE)



WAYNE BURNER - Serial No. M5895 & Beyond



WAYNE BURNER - Serial No. M5659 & Lower




FOR BURNER TECHNICAL ASSISTANCE CALL 1-800-443-4625

WIRING DIAGRAM HONEYWELL RA7895 30 SEC. CSD1 LC ON-OFF HWP 63780-003



MIDCO BURNER VG1000




SENSOR RESISTANCE CHART


Degrees Farenheight	Degrees Celcius	Resistance (1K Ohm Scale)*	Degrees Farenheight	Degrees Celcius	Resistance (1K Ohm Scale)*
-40	-40	330.6	185	85	1.07
-31	-35	239	194	90	0.9156
-22	-30	174.7	203	95	0.7862
-13	-25	129	212	100	0.6777
-4	-20	96.21	221	105	0.5863
5	-15	72.42	230	110	0.5089
14	-10	55.01	239	115	0.4433
23	-5	42.14	248	120	0.3873
32	0	32.55	257	125	0.3395
41	5	25.34	266	130	0.2985
50	10	19.87	275	135	0.2633
59	15	15.7	284	140	0.2328
68	20	12.49	293	145	0.2065
77	25	10	302	150	0.1836
86	30	8.059	311	155	0.1636
95	35	6.534	320	160	0.1455
100	40	5.329	329	165	0.1303
113	45	4.371	338	170	0.1169
122	50	3.604	347	175	0.1052
131	55	2.988	356	180	0.09484
140	60	2.489	365	185	0.08569
149	65	2.084	374	190	0.07757
158	70	1.753	383	195	0.07037
167	75	1.481	392	200	0.06396
176	80	1.256			

* Correct Ohm reading when sensors are at the above listed temperatures


CONTROL BOX MAIN CIRCUIT DIAGRAM




CONTROL BOX WIRING DIAGRAM



CONTROL BOX WIRING





CONTROL BOX PARTS



Item #	Part #	Description
1	HWP 23000	Motor Contactor (K1M)
2	HWP 22700	Burner Contactor (K2)
3	HWP 25700	Control Relay (K3)
4	HWP 20582	Fan and Burner Sensor
5	HWP 20579	Heater Control Unit
6	HWP 21400	Over Heat Reset
7	HWP 120021	Control Switch
8	HWP 44120	Light Green
9	HWP 44110	Light Red
10	HWP 2453	Thermostat
11	HWP 36701	Terminal Block (Heater Control)
12	HWP 36609	Terminal Block (Control Box) 6mm
13	HWP 38107	Circuit Breaker 32 AMP (F1-F2)
14	HWP 38105	Circuit Breaker 20 AMP (F3)
15	HWP 38090	Circuit Breaker 6 AMP (F5-F6)
16	HWP 40500	Main Control Box (Box Only)
17	HWP 38209	Thermostat Box (Box Only)
18	HWP 38209	Thermal Relay (F4)
19	HWP 36610	Terminal Block (Control Box 4mm)
20	HWP 22211	Aux Contact

EXHAUST FLUE PIPE GUIDELINES



CAPACITY OF
TYPE B DOUBLE-
WALL VENTS
SERVING A SIN-
GLE DRAFT
HOOD-HEATER x
1000 BTU'S

FOR INDOOR
APPLICATIONS

TOTAL VENT HEIGHT (H) FEET	LATERAL LENGTH (L) FEET	VENT DIAMETER (D) INCHES							
		10	12	14	16	18	20	22	24
6	0	NR	850	1170	1530	1960	2430	2950	3520
	2	NR	650	890	1170	1480	1850	2220	2670
	6	NR	630	870	1150	1470	1820	2210	2650
	12	NR	610	840	1110	1430	1795	2180	2600
8	0	NR	970	1320	1740	2220	2750	3360	4010
	2	NR	745	1020	1340	1700	2110	2560	3050
	8	NR	720	1000	1320	1670	2070	2530	3030
	16	NR	685	950	1260	1600	2035	2470	2960
10	0	NR	1060	1450	1925	2450	3050	3710	4450
	2	NR	850	1130	1480	1890	2340	2840	3390
	10	NR	795	1080	1430	1840	2280	2780	3340
	20	NR	735	1030	1360	1780	2230	2720	3250
15	0	NR	1240	1720	2270	2900	3620	4410	5300
	2	NR	985	1350	1770	2260	2800	3410	4080
	15	NR	905	1250	1675	2150	2700	3300	3980
	30	NR	845	1180	1550	2050	2620	3210	3840
20	0	NR	1350	1900	2520	3250	4060	4980	6000
	2	NR	1100	1520	2000	2570	3200	3910	4700
	10	NR	1045	1460	1940	2500	3130	3830	4600
	20	NR	990	1390	1880	2430	3050	3760	4550
30	30	NR	945	1270	1700	2330	2980	3650	4390
	0	1060	1550	2170	2920	3770	4750	5850	7060
	2	865	1310	1800	2380	3050	3810	4650	5600
	20	784	1185	1650	2200	2870	3650	4480	5310
	40	705	1075	1520	2060	2700	3480	4270	5140

SETTING THE PILOT FOR THE VG1000 WITH THE MIDCO BURNER

Setting the pilot light on the Midco burner should be your first priority after your correct, initial, basic set-up.

Remember, these instructions are for the Midco burner only!

To set the pilot on the VG1000's with the Midco burner, you will need a few tools of the trade, and they are as follows:


- 1) A multi-meter (voltmeter) that is capable of reading D.C. voltages
- 2) An adjustable wrench
- 3) A small slotted screwdriver
- 4) A low pressure gas gauge capable of measuring inches of water column

When the VG1000 has been placed at your desired location and your basic set up has been accomplished (Correct flue piping, correct electrical set-up, and correct gas supply set-up), we will need to make sure we have the correct pilot orifice. The correct propane pilot orifice is part# 6772-09 and will be stamped “.046”, and the natural gas orifice (part# 6772-08) will be stamped “.052”.


SETTING THE PILOT

1. Install the correct pilot orifice for the fuel source. The pilot orifice is located at the back of the drawer assembly, at the end of the pilot gas line.
2. Remove the 1/8” pipe plug on top of the pilot orifice and install the low pressure gauge.
3. Make sure your air damper (located on the right hand side of the burner) is open at least half way using your adjustable wrench to loosen and then tighten the nut for the air damper.
4. Set your multi-meter for D.C. volts and insert the meter probes into the test ports located on the blue Honeywell flame safeguard control. Make sure that the red (positive) lead is inserted into the “+” port and the black (negative) lead is inserted into the “-“ port. You need to adjust your leads as needed to make sure they make a good electrical connection!
5. Close the main 1-1/4” ball valve and bleed all of the air from the supply line thru the 1/8” pipe plug next to the 1/4” ball valve.
6. Start the heater.
7. Make sure you have the correct pilot pressure for your gas set up. For both propane and natural gas, the correct pilot pressure is 4” W.C.. If your pilot pressure is not correct, you will need to remove the cap on your pilot regulator using your slotted screwdriver and adjust your pressure accordingly.
8. Once you have your correct pilot pressure set, check your voltmeter for a D.C. volt reading. A minimum of 2 volts D.C. is required to prove flame but ideally, we would like to see a higher reading.
9. Now, you need to loosen the nut on your air damper and slowly open or close your damper while watching your multi-meter. As you open (or close) your damper, your voltage reading on your meter should rise. Keep adjusting your damper SLOWLY until your meter starts to drop and then slowly move your damper back until your meter has its highest D.C. volt reading. Then, tighten the air damper nut when you have reached the highest voltage reading.
10. Now, you can open your 1-1/4” ball valve back open and your heater should have gas to the main burner.
11. Now, you can adjust the main burner pressure by removing the cap to your regulator and setting your correct manifold pressure. For propane, the correct manifold pressure is 2.6” W.C. and for natural gas, the pressure should be set at 4.1” W.C.

We Stock A Complete Line Of Parts & Accessories



DUCTING



THERMOSTAT
LOCK BOXES



HOSES



REGULATORS



342 N. Co. Rd. 400 East
Valparaiso, IN 46383
219-464-8818 • Fax 219-462-7985
www.heatwagon.com